



- NOTES:**
1. PRESSURE REDUCING VALVE TO LIMIT MAINS PRESSURE TO 200kPa.
  2. PUMP PRESSURE "ON" SETTING MUST BE SET TO 250kPa OR HIGHER TO ENSURE SUPPLY IS FROM TANK WHEN RAINWATER IS AVAILABLE.

**INTERCONNECTION DEVICE SCHEMATIC**

- LEGEND:**
- RAINWATER PIPEWORK
  - MAINS PIPEWORK (POTABLE SUPPLY)
  - ISOLATION VALVE/STOP TAP
  - WATER METER

**PLUMBING SCHEMATIC**  
**HOUSING NSW RAINWATER TANK STANDARD DRAWING**  
**COMMUNAL RAINWATER TANK CONFIGURATION**  
**PLUMBING SCHEMATIC**

NOT TO SCALE  
 Revision 3 - 28 August 2009